

Y45

Yamaha MT-09 2017- Fitting kit right side:

Fitting kit left side:

ID	Description	Cat.	QTY
1	Steel box	X1	1
2	Al.spacer d=40mm	1237	1
3	Bolt M10x115x1,25	894	1

ID	Description	Cat.n	QTY
1	Steel box	X1	1
2	Alu.spacer d=28mm	1238	1
3	Bolt M10x100x1,25	892	1

Instruction to assembly left side:

1. Take out original bolt from frame.
2. Insert steel box ID.1 into the protektor.
3. Put bolt ID.3 into the protector, under the protector put dural.spacer ID.2 and into the frame insert ID.2.
4. This set mount into the frame.

Instruction to assembly right side:

1. Take out original bolt from frame.
2. Insert steel box ID.1 into the protektor
3. Put bolt ID3 into the protector and put on it al.cylinder ID.2.
4. This set mount into the frame.

Warning: Use the glue of all threads. Medium strong.

