



# KTM10S

## KTM 390 Duke 2018-

### Kit for left side

ID.	Description	Cat. No.	Pcs.
1	Dural.adapter for SL01	315	1
2	Dural. roller d=13mm	464	1
3	Dural. roller d=15mm	465	1
4	Bolt M10x45	847	1
5	Bolt M8x45mm	964	2
6	Steel adapter	628	1
7	Bolt M6x25	877	3
8	Bolt M4x16	876	2

### Kit for right side

ID.	Description	Cat. No.	Pcs.
1	Dural.adapter for SL01	315	1
2	Dural. roller d=17mm	1190	1
3	Dural. roller d=17mm	1190	1
4	Bolt M10x45	847	1
5	Bolt M8x45mm	964	2
6	Steel adapter	628	1
7	Bolt M6x25	877	3
8	Bolt M4x16	876	2

### Mounting instructions:

1. Mounting procedures of the crash protectors is the same for both sides.
2. Begin with one side only. First, take off the original M8 bolts.
3. Insert dural. rollers into the frame (ID.2 close to the front wheel and ID.3 to the rear wheel).
4. Use ID.5 bolts to attach the steel adapter ID.6 to the motorcycle frame.
5. Put the ID.4 bolt into the ID.1 dural. adapter.
6. Take this assembly and mount it onto the steel adapter on the motorcycle frame (as shown on attached pictures).
7. Finally, mount the slider with ID.7 bolts and insert the cover into the protector. Fix it with ID.8 bolts.

**Note – We recommend using medium strength glue for threads of all screws (blue color).**

