

# BN6

## Benelli BN302R '17-

### Mounting kit – Right side

ID	Description	Cat.No	Pcs
1	Steel adapter BN6-P	724	1
2	Bolt M10x50	996	1
3	Bolt M10x60 hex	850	1
4	Steel insert	X1	1
5	Dural. sleeve l=20mm	DV2	1
6	Flat washer M10	804	1
7	3M tape		2

### Mounting kit – Left Side

ID	Description	Cat.No	Pcs
1	Steel adapter BN6-L	723	1
2	Bolt M10x50	996	1
3	Bolt M10x60 hex	850	1
4	Steel insert	X1	1
5	Dural. sleeve l=20mm	DV2	1
6	Flat washer M10	804	1
7	3M tape		2

### Mounting instructions:

1. Remove original plastics on both sides.
2. Mount the steel adapter (ID1) in the motorcycle frame using M10 bolt (ID2) and M10 washer (ID6) – do not tighten the bolt, cover the possible places of contacts with 3M tape (ID 7) –see the photo.
3. Put the plastics back on the motorcycle and tighten the bolts.
4. Place the insert (ID4) in the protector, insert the M10 bolt (ID3), put the sleeve (ID5) on the bolt. Install this assembly in the steel adapter (ID1).
5. Use the same mounting procedure on the other side of the motorcycle.

**Warning - We recommend using medium strength thread glue during assembly.**



