

C1S

Cagiva Raptor 1000

Kit for left side:

ID	Description	Cat.no	Qty
1	Adapter SL d=20mm	DV1137	1
2	Bolt M12x125x1,25mm	952	1
3	Dural.cylinder d=85mm	1192	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2

Kit for right side:

ID	Description	Cat.no	Qty
1	Adapter SL d=20mm	DV1137	1
2	Bolt M12x150x1,25mm	984	1
3	Dural.cylinder d=105mm	1193	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2

Instruction to assembly:

- 1) Take out original bolt from frame on the left side.
- 2) Insert bolt M12 (ID2) through the adapter ID1, dural. cylinder ID3.
- 3) Mount this kit into the frame of motorcycle.
- 4) Fit slider on the adapter using three bolts M6 (ID4) and plate two bolts M4 (ID5).

We recommend to use the glue on all threads (medium strong).

