

D2SDM

Ducati Monster 600/625/695/750/800/900 900S/S2R/S4/S4R/S1000/S4RS 2001-

Left side mounting kit:

ID.	Description	Cat.no	Pcs
1	SLDM adapter	537/B	1
2	Nut M12	811	1
3	Dural. roller d=50mm	286	1
4	Bolt M6x20	1024	2
5	Washer M6	1023	2
6	Dural. roller d=50mm	208	1
7	Rod M12x470x30x30		1

Right side mounting kit:

ID.	Description	Cat.no	Pcs
1	SLDM adapter	537/B	1
2	Nut M12	811	1
3	Dural.roller d=50mm	286	1
4	Bolt M6x20	1024	2
5	Washer M6	1023	2
6	Dural. roller d=50mm	208	1

Montáž:

1. Remove original bolt M12 from the frame of motorcycle.
2. Insert the M12x470 ID.7 stainless steel rod through the 2nd frame
3. Put duralumin rollers (ID.3) on both sides of this stainless steel rod - wider in the right rollers ID.6.
4. Then insert the SLDM adapter ID.1 and remove it with the M12 ID.2 nuts
5. Finally, screw the slider with M6x20 ID.4 screws and M8 ID.5 washers.

We recommend to use the glue on all threads (medium strong).

