

D10SDM

Ducati Hyperstrada 821 (13-)

Mounting Kit for Left Side

ID	Description	Cat. No.	Pcs.
1	Slider adapter	537/B	1
2	Safety Nut M12	811	1
3	Dural. roller – 85mm	1199	1
4	Dural. roller d = 30mm	171	1
5	Bolt M6x20	1024	2
6	Washer M6	1023	2
7	Steel Rod 12x495x30x30	-	1

Mounting Kit for Right Side

ID	Description	Cat. No.	Pcs.
1	Slider adapter	537/B	1
2	Safety Nut M12	811	1
3	Dural. roller – 85mm	1199	1
4	Dural. roller d = 30mm	171	1
5	Bolt M6x20	1024	2
6	Washer M6	1023	2
7			

Instructions:

- 1.) Unscrew original bolts from the frame.
- 2.) Push the ID.7 Steel rod through the frame.
- 3.) Equip the ID.3 and ID.4 rollers onto both ends of the rod.
- 4.) Fit the ID.1 slider adapters after the dural. rollers and tighten the whole assembly with ID.2 M12 nuts.
- 5.) Finally, mount the slider onto the slider adapter with two ID.5 M8 bolts and ID.6 washers.

Use medium strenght blue color thread glue during installation.

