

D13SD

Ducati Scrambler 2015-

Left side kit

ID	Description	Cat.no.	pcs
1	SLD adapter	537	1
2	Nut M12	811	1
3	Washer M12	803	1
4	Dural. cylinder - 68,5mm	1212	1
5	Dural. adapter - 30mm	171	1
6	Washer M10 (stringed)	801	2
7	Bolt 8x25	815	2
8	Steel rod 12(1,25)x465x30x30		1

Right side kit

ID	Description	Cat.no.	pcs
1	SLD adapter	537	1
2	Nut M12	811	1
3	Washer M12	803	1
4	Dural. cylinder - 78,5mm	1213	1
5	Dural. adapter - 30mm	171	1
6	Washer M10 (stringed)	801	2
7	Bolt 8x25	815	2

Instructions:

1. Unsrew original bolt M12 from the frame of motorcycle.
2. Put steel rod M12 through the frame.
3. Put dural cylinders (ID4), adapters (ID5) SLD adapters (ID1) and steel washers (ID3) on both ends of steel rod.
4. Tighten both ends using nut M12.
5. Mount slider on the SLD adapter using two bolts (ID7) and washers (ID6).

We recommend to use the glue on all threads (medium strong).

