



# H29S

## Honda CBR250R 2011-

### Kit for the left side

ID.	Description	Cat.No.	Pcs
1	Steel adapter	640	1
2	Adapter under slider	315	1
3	Dural. roller (l=25mm)	467	1
4	Dural. washer (l=5mm)	16	1
5	Bolt M10x45mm	848	1
6	Bolt M6x60mm	872	1
7	Bolt M6x25	877	3
8	Bolt M4x12	876	2
9	Nut M10-insurance	810	1
10	Washer M10-flat	804	1
11	Washer M10-spring	801	1
12	Washer M6-flat	947	1
13	Steel rod	10x300x30x30	1

### Kit for the right side

ID.	Description	Cat.No.	Pcs
1	Steel adapter	641	1
2	Adapter under slider	315	1
3	Dural. roller (l=23,5mm)	468	1
4	Dural. washer (l=5mm)	16	1
5	Bolt M10x45mm	848	1
6	Bolt M6x60mm	872	1
7	Bolt M6x25	877	3
8	Bolt M4x12	876	2
9	Nut M10-insurance	810	1
10	Washer M10-flat	804	1
11	Washer M10-spring	801	1
12	Washer M6-flat	947	1

### Mounting :

1. Disassemble the original side plastics.
2. Remove the M6 and M10 bolts in the engine and motorcycle frame on the left side.
3. Mount the steel adapter (ID.1) on the motorcycle frame according to the attached photo below. For this assembly, use an M6x60mm screw (ID.6) with an M6 washer (ID.12) and a duralumin roller (ID.3), insert the duralumin roller under the steel adapter.
4. Use the original screw in the front upper part of the adapter.
5. Remove the M6 and M10 bolts in the engine and motorcycle frame on the right side.
6. In the front lower part of the adapter on the left side, push a steel rod (ID.13) through the frame.
7. Take the steel adapter for the right side (ID.1) and install it in the same way as on the left side.
8. Thread duralumin washers (ID.4) onto the steel rod in the lower part of both adapters and secure with nuts (ID.9) and M10 washers (ID.10). Dural washers belong under steel adapters.
9. Check and tighten everything, you can refit the side plastics.
10. Now start assembling the mount for the left slider. Mount the duralumin adapter under the slider (ID.2) on the steel adapter with a screw (ID.5) with a washer (ID.11).
11. Place the slider and fasten the screws (ID.7).
12. Insert the cover into the slider and fasten the screws (ID.8)
13. Mounting the slider on the right side is the same as mounting the left slider.

**Warning - on the threads of the screws is recommended to use premium adhesive moderate (blue color).**

