



# H49SD

## Honda NC750 DCT

### Kit for left side:

ID.	Description	Cat.No	Qty
1	Duralumin bracket	537	1
2	Bolt M12x90x1,25mm	919	1
3	Dural.reduction	DV149	1
4	Dural.cylinder d=50mm	209	1
5	Bolt M10x35mm	976	2
6	Steel adapter	655	1
7	Steel bracket	659	1
8	Washer M12	803	1
9	Tape 3M	3M	1
10	Bolt M8x25	815	2
11	Washer-spring M8	800	2
12	Bolt M12x80	956	1

### Kit for right side:

ID.	Description	Cat.N	Qty
1	Duralumin bracket	537	1
2	Bolt M12x80x1,25mm	891	1
3	Dural.cylinder d=11mm	17	1
4	Dural.reduction d=90mm	157	1
5	Bolt M12x110	946	1
6	Bolt M10x35mm	976	2
7	Steel adapter	654	1
8	Steel bracket	656	1
9	Washer M12	803	1
10	Tape 3M	3M	1
11	Bolt M8x25	815	2
12	Washer-spring M8	800	2
-		-	-

### Instruction to left side:

1. Dismantle lower fairing and original bolt from frame M12.
2. Steel adapter ID.6 mount on the frame use bolt M12x90x1,25mm ID.2 and washer M12 ID.8.
3. Steel bracket ID.7 mount by bolts M10x30mm ID.5. Stick on 3M tape ID.9 on frame.
4. On the bolt ID.12 insert dural.bracket ID.1, under the bracket put reduction ID.3 with cylinder ID.4.
5. This kit mounting on the steel adapter ID.6. For slider gripping use bolts and washers ID.11 and ID.10.

### Instruction to right side:

1. Take out coolant bottle and original bolt M12 from frame.
2. Mount steel adapter ID.7 same so on the left side, but between the frame and adapter inser dural. cylinder d=11mm ID.3.
3. Steel bracket with threads ID.8 put on the back side to frame and mount by bolts ID.6.
4. Mount back coolant bottle on the bike.
5. On the bolt ID.5 insert dural.bracket ID.1, under the bracket put reduction ID.4.
6. This kit mounting on the steel adapter ID.7. For slider gripping use bolts and washers ID.11 and ID.12.

**Put fairing back on the bike.**

**Warning – use glue of all threads- medium strong.**

Illustration photos with PH protectors

