

# H55S

## Honda CBR 1000rr '2017-

### Kit left side:

ID	Description	Cat. No.	Pcs.
1	SL adapter d=45mm	DV313	1
2	Bolt M12x55x1,25mm	975	1
3	Bolt M10x45mm	848	1
4	Steel adapter H55-L	726	1
5	Tape 3M	-	1
6	Plastic panel -L	730	1
7	Bolt M6x25	877	3
8	Bolt M4x16	876	2
9	Duralamid roller d=10mm	DV1	1

### Kit right side:

ID	Description	Cat. No.	Pcs.
1	SL adapter d=45mm	DV313	1
2	Bolt M12x60x1,25mm	916	1
3	Bolt M10x45mm	848	1
4	Steel adapter H55-P	727	1
5	Tape 3M		1
8	Plastic panel -P	731	1
9	Bolt M6x25	877	3
10	Bolt M4x16	876	2
11	Duralamid roller d=10mm	DV1	1

### Mounting instructions – left side:

1. Remove the original plastic from side and M12 bolt from the motorcycle frame.
2. Attach the 3M tape (ID.5) to the point where motorcycle frame meets ID.2 blt and tighten the steel adapter towards the motorcycle frame.
3. Replace the original black plastic with plastic panel (ID.6) at the rear hood.
4. Check that everything is in place and proceed to return the side plastic to its place.
5. Insert the M10 bolt (ID.3) into the SL adapter (ID.1) and dural. roller (ID.9)
6. Mount the full assembly into the adapter thread.
7. Finally, attach the slider using ID.11 bolt and finish fitting the cover plate with ID.8 bolts.

### Mounting instructions – right side:

1. Remove the original plastic from side and M12 bolt from the motorcycle frame.
2. Attach the 3M tape (ID.5) to the point where motorcycle frame meets ID.2 blt and tighten the steel adapter towards the motorcycle frame.
3. Replace the original black plastic with plastic panel (ID.6) at the rear hood.
4. Check that everything is in place and proceed to return the side plastic to its place.
5. Insert the M10 bolt (ID.3) into the SL adapter (ID.1) and dural. roller (ID.9)
6. Mount the full assembly into the adapter thread.
7. Finally, attach the slider using ID.7 bolt and finish fitting the cover plate with ID.8 bolts.

8. **Note - we recommend using medium strenght glue (blue color) for threads of all screws.**

