

K8

Kawasaki ZRX1200 2001-

Kit for left side:

ID.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M10x150mm	939	1
3	Dural.cylinder d=80mm	198	1
4	Nut M10	814	1

Kit for right side:

ID.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M10x130mm	883	1
3	Dural.cylinder d=60mm	196	1
4	Nut M10	814	1



Assembly :

1. Installation of the left and right protector make in gripping about the attached photo above.
2. Give the steel box M10 ID.1 on both bolts. Put the duralumin cylinder ID.3 under the protector on the left side and use the bolt ID.2 together with nut ID.4 for tightening. Put the duralumin cylinder ID.3 under the protector on the right side and use the bolt ID.2 together with nut ID.4 for tightening. At first finish the one side and then mount the second side.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

