

K34-2

Kawasaki ZX636R Ninja, '13-'14

Fitting kit left side:

ID	Description	Cat.n	QTY
1	Steel box	X1	1
2	Dural.adapter	1128	1
3	Bolt M10x80x1,25	920	1

Fitting kit right side:

ID	Description	Cat.n	QTY
1	Steel box	X1	1
2	Dural.adapter	1129	1
3	Bolt M10x90x1,25	890	1

Instruction to assembly left side:

1. Take out original bolt M10 from frame.
2. Insert steel box ID.1 into the protector.
3. Insert bolt ID.3 M10x80 into the protector and put on it dural.adapter ID.2.
4. This set instal into the frame.

Instruction to assembly right side:

1. Take out original bolt M10 from frame.
2. **Don't dismantle special crown nut!**
3. Insert steel box ID.1 into the protector.
4. Insert bolt ID.3 M10x80 into the protector and put on it dural.adapter ID.2.
5. This set instal into the frame.

Warning : Use the glue of all threads-medium strong.

