

S40SD

Suzuki GSX-S1000 '16-

Left side:

ID	Description	Cat.	Qt
1	Dural. adapter	537	1
2	Bolt M10x90x1,25	890	1
3	Dural. cylinder - 20mm	1188	1
4	Dural. adapter (cylinder) – 15mm	DV9	1
5	Washer (stringed)	801	1
6	Washer M8	802	2
7	Bolt M8x25	815	2

Right side:

ID	Description	Cat.	Qt
1	Dural. adapter	537	1
2	Bolt M10x100x1,25	892	1
3	Dural. cylinder - 21,5mm	1189	1
4	Dural. adapter (cylinder) – 15mm	DV9	1
5	Washer (stringed)	801	1
6	Washer M8	802	2
7	Bolt M8x25	815	2

Instructions:

- 1.) We recommend to use the glue on all threads.
- 2.) Remove original bolt according to the picture.
- 3.) Prepare M10 bolt (ID2). Put stringed washer (ID5), dural. adapter (ID1), dural adapter (ID4) and dural. cylinder (ID3)* on bolt (ID2).
- 4.) Fit this kit on the frame of motorcycle.
- 5.) In the end fit protector on the adapter (ID1) using two bolts (ID7 + washers ID6).

*(note: dural adapter (ID3) is longer on the right side)

