

T16SD

Triumph Speed Triple 1050 2016-

Kit for Left Side:

ID.	Description	Cat.no.	Pcs
1	Dural. adapter for SLD	537	1
2	Dural. roller d=50mm	DV13	1
3	Bolt I M10x70mm	1007	1
4	Bolt M8x25	815	2
5	Washer M8	802	2
6	Dural. nut M22x1,5mm	446	1
7	Dural. bolt M22x1,5mm	447	1
8	Bolt M12x80mm	956	1
9	Washer M12	803	1
10	Nut M12	811	1
11	Washer - Spring M10	801	1

Kit for Right Side:

ID.	Description	Cat.no.	Pcs
1	Dural. adapter for SLD	537	1
2	Dural. roller d=50mm	DV13	1
3	Bolt I M10x70mm	1007	1
4	Bolt M8x25	815	2
5	Washer M8	802	2
6	Dural. nut M22x1,5mm	446	1
7	Dural. bolt M22x1,5mm	447	1
8	Bolt M12x80mm	956	1
9	Washer M12	803	1
10	Nut M12	811	1
11	Washer - Spring M10	801	1

Mounting Instructions – Left Side

1. Unscrew the original M12 bolt from motorcycle frame (attached to rear side by nut).
2. Use the special ID.6 nut and insert M12 ID.8 bolt into it.
3. Take this assembly and mount it onto the motorcycle frame, using ID.9 washer and ID.10 nut on rear side.
4. Now screw the special ID.7 bolt into the nut.
5. Push the M10x70 ID.3 bolt (with ID.11 washer) through the ID.1 adapter and ID.2 dural roller. Bring the adapter closer into the thread with the dural. bolt.
6. Mount and tighten the slider using ID.4 bolts, ID.5 washer.

Use the same procedure for Right Side.

We recommend using medium strenght thread glue during assembly.



