

Y50-2SD

Yamaha MT-10/SP 2022-

Kit for left side

Kit for right side

ID.	Description	Cat.No.	Pcs
1	Adapter under slider	537	1
2	Bolt M12x85x1,25mm	899	1
3	Dural. roller l=26mm	1398	1
4	Dural. roller l=15mm	9	1
5	Bolt M8x25mm	815	2
6	Washer M8	802	2

ID.	Description	Cat.No.	Pcs
1	Adapter under slider	537	1
2	Bolt M12x80x1,25mm	908	1
3	Dural. roller l=15mm	1397	1
4	Dural. roller l=15mm	9	1
5	Bolt M8x25mm	815	2
6	Washer M8	802	2

Assembly:

Install the left and right sliders in the bracket according to the photos below. Thread the adapters under the slider (ID.1), duralumin rollers (ID.4) and (ID.3) on both screws (ID.2) in exactly this order and mount them in the motorcycle frame. Finish one side first and then assemble the other. Then take the slider and mount the bolts (ID.5) with washers (ID.6) on the adapters that are mounted on the motorcycle.

Note: We recommend using medium strenght thread glue for all bolts (blue color).



