

A11

Aprilia Caponord 1200

Fitting kit left side:

ID.	Description	Cat.N	Qt
1	Steel nut M12	X12/X2	1
2	Alu spacer d=61mm	31	1
	Steel connection bar M12x425x(1,25)x30x30		1

Fitting kit right side:

ID.	Description	Cat.N	Qt
1	Steel nut M12	X12/X2	1
2	Alu spacer d=61mm	31	1

Assembly:

1. Dismantle original bolt M12.
2. Place steel bar into the frame M12x425x1,25mm
3. Place alu. spacers ID.2 on this bar from booth sides.
4. Tighten it by nuts ID.1.

Note: We recommend use medium strong glue for all threads.



