

B2SD

BMW K1200R/K1200R Sport 2005-

LEFT SIDE KIT

ID	Description	Cat.no	Pcs
1	SLD adapter	537	1
2	Bolt M10x110x1,5mm	879	1
3	Dural. cylinder 26mm	418	1
4	Dural. cylinder 15mm	9	1
5	Bolt M8x25	815	2
6	Washer M8	800	2
7	Washer M10	801	1

RIGHT SIDE KIT

ID	Description	Cat.no	Pcs
1	SLD adapter	537	1
2	Bolt M10x100x1,5mm	885	1
3	Dural. cylinder 16mm	419	1
4	Dural. cylinder 15mm	9	1
5	Bolt M8x25	815	2
6	Washer M8	800	2
7	Washer M10	801	1

INSTRUCTIONS

- 1) Put washer ID7, SLD adapter (ID1) and dural cylinder ID4+ID3 on the bolt ID2.
- 2) Mount this kit into the frame of motorcycle.
- 3) Fit diamond using two bolts ID5 and washers ID6.

We recommend to use safety glue on all threads.

