

B9

BMW F800 R 2014-

Fitting kit left side:

ID	Description	Cat.N	Qt
1	Steel adapter	675	1
2	Alu. spacer d=29,5	1154	1
3	Alu. spacer d=6mm	1105	1
4	Bolt M10x110	879	1
5	Bolt M10x85	981	1
6	Washer M10	804	2
7	Plastic cap	X4	2
8	Bolt M10x35	847	1
9	Steel box	X1	1

Fitting kit right side:

ID	Description	Cat.N	Qt
1	Steel adapter	675	1
2	Alu. spacer d=41mm	1153	1
3	Alu. spacer d=13mm	1155	1
4	Bolt M10x120	881	1
5	Bolt M10x90	880	1
6	Washer M10	804	2
7	Plastic cap	X4	2
8	Bolt M10x35	847	1
9	Steel box	X1	1





Assembly left side:

1. Dismantle original bolts M10 from chassi.
2. Insert bolt ID.4 front gripping with washer ID.6 into the steel adapter ID.1.
Rear gripping use bolt ID.5 + washer ID6.
3. Into the frame place spacers. Front spacer is ID.2 rear is ID.3.
4. Tighten bolts M10.
5. Place plastic covers into head bolts.
6. Into teh crash bobbin insert steel box ID.9 and fix protector by bolt ID.8

Assembly right side:

1. Dismantle original bolts M10 from chassi.
2. Insert bolt ID.4 front gripping with washer ID.6 into the steel adapter ID.1.
Rear gripping use bolt ID.5 + washer ID6.
3. Into the frame place spacers. Front spacer is ID.2 rear is ID.3.
4. Tighten bolts M10.
5. Place plastic covers into head bolts.
6. Into teh crash bobbin insert steel box ID.9 and fix protector by bolt ID.8

During assembly use medium strong glue for all treads.