

D9

Ducati Hypermotard 821/939 '16- Ducati Hyperstrada 939 '16-

Kit for the left side

No.	Description	Cat.no	Pcs
1	Steel nut M12	X12/X2	1
2	Duralumin cylinder d=90mm	1200	1
	Stainless steel bar 12(1,25)x435x30x30		1

Kit for the right side

No.	Description	Cat.no	Pcs
1	Steel nut M12	X12/X2	1
2	Duralumin cylinder d=85mm	1199	1

Installation:

1. dismount the long original bolt M12
2. insert through bar the stainless steel bar M12x445x1,25mm
3. give duralumin cylinder (No. 2) on this stainless steel bar both sides
4. finally screw up all with nuts M12 (No. 1)

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

