

D9S

Ducati Hypermotard 821/936 (16-) Ducati Hyperstrada 939 (16-)

Kit for the left side			
ID	Description	Cat.no.	Pcs
1	Slider adapter	DV314	1
2	Steel nut M12	X12	1
3	Dural. cylinder – 90mm	1200	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2
6	Steel rod 12(1,25)x455x30x30	-	1

Kit for the right side			
ID	Description	Cat.no.	pcs
1	Slider adapter	DV314	1
2	Steel nut M12	X12	1
3	Dural. cylinder – 85mm	1199	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2
-	-	-	-

Instructions:

- 1.) Remove original bolt from frame of motorcycle.
- 2.) Insert steel rod (ID6) through the frame.
- 3.) Mount cylinders (ID3 – longer on the left side) on both ends of steel rod.
- 4.) Mount slider adapters (ID1) behind cylinders and tighten this set using steel nut (ID2).
- 5.) Fit slider on the slider adapter using three bolts M6 (ID4).
- 6.) Fit coloured cover using two M4 bolts (ID5).

