

# H11-2

## Honda CBR900RR 1996-1999

### Kit for the left side

No.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M12x105x1,25mm	893	1
3	Dural. cylinder d=40mm	161	1

### Kit for the right side

No.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M10x110x1,25mm	928	1
3	Dural. cylinder d=40mm	161	1





## **Intallation:**

**You will have to drill the hole in the cowl during installation. It is therefore necessary intervention in the original cowl!**

Installation of the left and right protector make in gripping about the attached photo above. Give the steel box M10 (No. 1) on both bolts. Put the duralumin cylinder (No. 3) under the protector on the left side and use the bolt (No. 2) for tightening. Put the duralumin cylinder (No. 3) under the protector on the right side and use the bolt (No. 2) for tightening. At first finish the one side and then mount the second side.

**Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).**