

H46

Honda NC750 X/S

Kit for left side:

ID.	Description	Cat.No	Qty
1	Steel box M12	X2	1
2	Bolt M12x90x1,25mm	919	1
3	Dural.cylinder d=40mm	1125	1
4	Bolt M12x75	807	1
5	Bolt M10x35mm	976	2
6	Steel adapter	654	1
7	Steel bracket	656	1
8	Washer M12	803	1
9	Tape 3M		1

Kit for right side:

ID.	Description	Cat.No	Qty
1	Steel boxM12	X2	1
2	Bolt M12x80x1,25mm	891	1
3	Dural.cylinder d=11mm	17	1
4	Dural. cylinder d=30mm	170	1
5	Bolt M12x65	963	1
6	Bolt M10x35mm	976	2
7	Steel adapter	655	1
8	Steel bracket	659	1
9	Washer M12	803	1
10	Tape 3M		1

Instruction to left side:

1. Dismantle fairing and original bolt from frame M12.
2. Steel adapter ID.6 mount on the frame use bolt M12x90x1,25mm ID.2 and washer M12 ID.8.
3. Steel bracket ID.7 mount by bolts M10x30mm ID.5. Stick on 3M tape ID.9 on frame.
4. Use bolt M12x75mm ID.4 and mount crash protector. Insert steel box ID.1 into the protector under the protector put dural. cylinder d=40mm ID.3.

Instruction to right side:

1. Take out coolant bottle and original bolt M12 from frame.
2. Mount steel adapter ID.7 same so on the left side, but between the frame and adapter insert dural. cylinder d=11mm ID.3.
3. Steel bracket with threads ID.8 put on the back side to frame and mount by bolts ID.6.
4. Use bolt M12x65mm ID.5 and Mount crash protector M12 ID.1 insert steel box into the protector and under the protector insert dural. cylinder d=30mm ID.4
5. Mount back coolant bottle on the bike.

Warning – use glue of all threads- medium strong.

