

H60SD

Honda MSX 125_2017-

Fitting kit left side:

ID	Description	Cat.n	QT
1	Mounting plate	690	1
2	Dural.spacer l=57mm	1166	1
3	Engine bar l=225mm	10x225 X30x30	1
4	Nylon cut nuts M10	810	2
5	Washer M10	804	2
6	Bolt M6x40	865	2
7	Dural. spacer l=10mm	1164	1
8	Dural. spacer l=9mm	1165	1

Fitting kit right side:

ID	Description	Cat.	QT
1	Mounting plate	725	1
2	Dural.spacer l=21mm	1158	1
3	Conecting bar l=230mm	10x230 x30x30	1
4	Nylon cut nuts M10	810	2
5	Washer M10	804	2
6	Bolt M6x50	972	1

Assembly kit for protectors:

ID	Description	Cat.n	QTY
9	Plastic cover	X35	4
10	Dural. spacer l=60mm	14	1
11	Dural. spacer l=90mm	238	1
12	Bolt M10x90	880	1
13	Bolt M10x120	881	1
14	Washer spring M10	801	2
15	Nylon nut cut M10	810	2
16	Dural. holder for SLD	537	2
17	Bolt M8x25	815	4
18	Washer M8	800	4

Instruction to assembly:

1. Remove the nut on the engine bolt on the left side of the bike.
2. Remove original bolt from the engine.
3. Remove the engine case bolts 2 pices from the left side, 1 piece from the right side.
4. Take the shorter engine bar l=225mm ID.3 and insert it thru the engine (replace original bolt).
5. Place dural. cylinder l=57mm ID.2. on the bar from the left hand side. Place dural. cylinder l=21mm ID.2. on the bar from the right hand side. Place mounting plates from right side and tighten it by nylonce nuts ID.4 and place washer ID.5.
6. Make assembly mounting plates into the engine case, use bolt ID.6
7. The mounting plate assembly can now be offerd up the right side of the bike. Conecting bar insert in front of the engine and do assembly. Connecting bar tighten by nut ID.4 and washer ID.5.

8. Now you can make assembly left side. Bolts ID.6 place throught the mounting plate. There are two dural. spacers. The porter spacer l=9mm is insert on the bolt place down.
9. Insert mounting plate on the engine bar and connecting bar.
10. Two bolts M6 with spacers mounting into the engine case.
11. Tighten mounting plate by nuts ID.4 and washers ID.5.
12. After this chec all bolts and nuts, now you can put plastic covers ID.9.

Crash protecotrs assembly instruction:

1. Left side:

2. Dural. bracket ID.16 with dural. spacer ID.10 (porter) place on the bolt ID.12. This kit mounting from back side by nut and washer ID.14, ID.15 into the mounting plate on the engine.
3. Slider mounting on the dural. holder by bolts ID.17 with washers ID.18.

4. Right side:

5. Dural. bracket ID.16 with dural. spacer ID.11 place on the bolt ID.13.
6. This kit mounting from back side by nut and washer ID.14, ID.15 into the mounting plate on the engine.
7. Slider mounting on the dural. holder by bolts ID.17 with washers ID.18.

Warning: We recommend use the glue of all threads. Medium strong.



