

K13S

Kawasaki Z1000 2007-2009

Fitting kit left side:

ID	Description	Cat.N	Qty
1	Dural.adapter SL01	313	1
2	Bolt M10x30mm	882	1
3	Bolt M6x25	877	3
4	Bolt M4x16	876	2
5	Bolt M8x60mm	838	2
6	Dural.cylinder d=14mm	18	2
7	Dural.adapter	547	1
8	Washer spring M10	801	1
9	Plastic cap	X5	2
10	3M tape		1

Fitting kit right side:

ID	Description	Cat.N	Qty
1	Dural.adapter SL01	292	1
2	Bolt M10x35mm	847	1
3	Bolt M6x25	877	3
4	Bolt M4x16	876	2
5	Bolt M8x60mm	838	2
6	Dural.cylinder d=14mm	18	2
7	Dural.adapter	547	1
8	Plastic cap	X5	2
9	3M tape		1
10	Washeer spring M10	801	1



Instruction to assembly left side:

1. Take out original bolts from frame M8.
2. Mounting dural.adapter ID.7 on frame. Use bolts ID.5 and into the frame put dural.cylinders ID.6.
3. You can stick 3M tape under the dural. adapter ID.7.
4. Put plastic cover into the bolts ID.9.
5. Grip dural.adapter ID1 on the bike. Use bolt ID.2 and washer ID.8
6. Mounted slider on the adapter, use bolts ID.3.
7. Insert cover into the slider, use bolts ID.4.

Instruction to assembly right side:

1. Take out original bolts from frame M8.
2. Mounting dural.adapter ID.7 on frame. Use bolts ID.5 and into the frame put dural.cylinders ID.6.
3. You can stick 3M tape under the dural. adapter ID.6.
4. Put plastic cover into the bolts ID.8.
5. Grip dural.adapter ID1 on the bike Use bolt ID.2 and washer ID.10.
6. Mounted slider on the adapter, use bolts ID.3.
7. Insert cover into the slider, use bolts ID.4.

Warning: We recommend use the glue of all threads. Medium strong.



Foto staršího typu uchycení slideru.