



# K15S

## Kawasaki ZX-10R 2008-2010

### Kit for the left side

No.	Description	Cat.no.	Pcs
1	Slider RDMoto	SL	1
2	Cover	SLcap..	1
3	Adapter moto	DV-315	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2
6	Steel adapter	555	1
7	Bolt M10x50x1,25mm	921	1
8	Bolt M10x50mm	849	1
9	Washer M10 (spring)	801	1
10	Dural. cylinder d=10mm	113	1
11.1	Steel rod M10x415x30x30	AL16	1
12	Tape 3M		

### Kit for the right side

No.	Description	Cat.no.	Pcs
1	Slider RDMoto	SL	1
2	Cover	SLcap..	1
3	Adapter moto	DV-317	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2
6	Steel adapter	556	1
7	Bolt M10x50x1,25mm	921	1
8	Bolt M10x30mm	882	1
9	Washer M10 (spring)	801	1
10	Dural. cylinder d=4mm	112	1
11.2	Bolt M10x30mm (cone)	846	1
12	Tape 3M		

### Installation:

- 1.) Remove fairing of motorcycle.
- 2.) Remove original bolts M10 from the frame.
- 3.) Stick 3M tape on the frames on both sides according to the picture.
- 4.) Use bolt M10 (ID7) for tightening rear part of steel adapter ID6. Place washers ID9 and cylinders ID10 on the bolt.
- 5.) Prepare steel rod ID11.1 and place it between adapters into front threads of adapters.
- 6.) Fit steel rod using cone bolt ID11.2 on the right side.
- 7.) On the left prepare bolt ID8. Insert this bolt into adapter ID3 and mount this kit through front thread into the steel rod.
- 8.) Now fit right side adapter ID3 using bolt ID8.
- 9.) Mount slider on the adapter using three bolts M6.
- 10.) In the end mount coloured cover using two bolts M4.

**Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).**

