



K25SD

Kawasaki ZX-6R/RR 2009-2011

LEFT SIDE KIT

ID	Description	Cat.No.	Pcs
1	SLD adapter (cylinder) 20mm	DV10	1
2	Bolt M10x58x1,25mm	944	1
3	Bolt M6x20mm	878	1
4	Bolt M10x40mm	854	1
5	Dural. cylinder 8mm	229	1
6	Poly. Nut 10mm	227	1
7	Dural. adapter	541	1
8	3M tape		1
9	SLD adapter	537	1
10	Bolt M8x25	815	2
11	Washer M8	800	2
12	Washer M10 (spring)	801	1

RIGHT SIDE KIT

ID	Description	Cat.No.	Pcs
1	SLD adapter (cylinder) 15mm	DV9	1
2	Bolt M10x70x1,25mm	898	1
3	Bolt M6x20mm	878	1
4	Bolt M6x25mm	877	1
5	Bolt M10x30mm	882	1
6	Poly. Nut 10mm	227	1
7	Poly. Nut 15mm	228	1
8	Dural. adapter	542	1
9	SLD adapter	537	1
10	Bolt M8x25	815	2
11	Washer M8	800	2
12	3M tape		1

LEFT SIDE INSTRUCTIONS

- 1) Dismantle side fairing and original bolts.
- 2) Prepare adapter according to the picture. Mount this kit on the frame of motorcycle.
- 3) Mount side fairing back.
- 4) Put washer ID12, SLD adapter ID9 and dural. cylinder ID1 on the bolt ID4. Fit this kit into the adapter on the motorcycle.
- 5) Fit slider using two bolts ID10 and washers ID11.

We recommend to use safety glue on all threads (medium strong).



RIGHT SIDE INSTRUCTIONS

- 1) Dismantle side fairing and original bolts.
- 2) Prepare adapter according to the picture. Mount this kit on the frame of motorcycle.
- 3) Mount side fairing back.
- 4) Put SLD adapter ID9 and dural. cylinder ID1 on the bolt ID5. Fit this kit into the adapter on the motorcycle.
- 5) Fit slider using two bolts ID10 and washers ID11.

We recommend to use safety glue on all threads (medium strong).



