

K31

Kawasaki ER-6F 2013-

Kit for the left side

No.	Description	Cat.No	Pcs
1	steel insert M10	X1	1
2	screw M10x80mm	852	1
3	duralumin cylinder d = 40mm	469	1
4	screw M8x70mm	841	2
5	steel adapter	639	1
6	nut M10-insurance	810	1
7	pad M10 flat	804	1

Kit for the right side

No.	Description	Cat.No	Pcs
1	steel insert M10	X1	1
2	screw M10x80mm	852	1
3	duralumin cylinder d = 40mm	469	1
4	screw M8x70mm	841	2
5	steel adapter	638	1
6	nut M10-insurance	810	1
7	pad M10 flat	804	1

Mounting - left side:

1. remove the original plastic side and screws M8 of the motorcycle frame
2. by screws (item 4) mount on the motorcycle frame steel adapter (item 5)
3. to the crash protector insert a steel insert (item 1) and screw (item 2)
4. from the back side of crash protector insert to the screw duralumin cylinder (item 3)
5. entire assembly mount on the steel adapter and tighten by nut (item 6) with pad (item 7)
6. mount back the plastic side

Warning - the threads of the screws is recommended to use premium adhesive moderate (blue color).



Mounting - right side:

1. remove the original plastic side and screws M8 of the motorcycle frame
2. by screws (item 4) mount on the motorcycle frame steel adapter (item 5)
3. to the crash protector insert a steel insert (item 1) and screw (item 2)
4. from the back side of crash protector insert to the screw duralumin cylinder (item 3)
5. entire assembly mount on the steel adapter and tighten by nut (item 6) with pad (item 7)
6. mount back the plastic side

Warning - the threads of the screws is recommended to use premium adhesive moderate (blue color).

