



K29

Kawasaki ZX-10R 2011-

Kit for the left side

No.	Description	Cat.no	Pcs
1	Steel box M10	X1	1
2	Bolt M10x90x1,25mm	890	1
3	Dural. cylinder d=30,5mm	290	1

Kit for the right side

No.	Description	Cat.no	Pcs
1	Steel box M10	X1	1
2	Bolt M10x95x1,25mm	927	1
3	Dural. cylinder d=14,5mm	291	1

Installation:

Installation of the left and right protector make in gripping about the attached photo above. Give the steel box M10 (No. 1) on both bolts. Put the duralumin cylinder (No. 3) under the protector on the left side and use the bolt (No. 2) for tightening. Put the duralumin cylinder (No. 3) under the protector on the right side and use the bolt (No. 2) for tightening. At first finish the one side and then mount the second side.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

