

CF71

Yamaha MT-09

Kit for Left Side			
ID	Description	Cat. No.	Pcs.
1	Frame		1
2	Bolt M10x125x1.25mm	924	1
3	Protector	PVPKN-0/16	1
4	Washer M10 flat	804	1
5	Dural. roller d=13mm	1127	1
6	Safety nut M10	810	1
7	Dural. insert to protektor	X131	1

Kit for Right Side			
ID	Description	Cat. No.	Pcs.
1	Frame		1
2	Bolt M10x115x1.25mm	894	1
3	Protector	PVPKN-0/16	1
4	Washer M10 flat	804	1
5	Dural. roller d=5mm	168	1
6	Safety nut M10	810	1
7	Dural. insert to protektor	X131	1
8	Rod 10x300x30x30mm		1

We recommed using medium strenght thread glue during assembly.

Instructions (same for both sides):

- 1.) Unscrew the original bolt from top part of the frame.
- 2.) Prepare the protector, (ID.2) bolt, insert (ID.7) and (ID.5) roller – depending on which side you are about to install.
- 3.) Attach the top part using M10 (ID.2) bolt.
- 4.) Now, unscrew the original bolt from bottom part of the frame.
- 5.) Now attach the (ID.8) rod, fit the rear part of the frame and tighten using M10 (ID.4) washers and (ID.6) nuts.
- 6.) Finally, tighten all.



