

Y36

Yamaha R1 2015

Kit for left side:

ID	Description	Cat.N	QTY
1	Steel box M12	X2	1
2	Bolt M12x95x1,25	900	1
3	Dural.spacer d=30	170	1

Kit for right side:

ID	Description	Cat.N	QTY
1	Steel box M12	X2	1
2	Bolt M12x70x1,25	937	1
3	Dural. roller d=5mm	1260	1

Instruction to assembly:

1. The first do assembly left side.
2. Please leave all spacer´s/bushes in place.
3. Take the protector for **left side**, insert steel box ID.1 into the protector.
4. Insert bolt through the protector and after insert dural.spacer ID.3 on the bolt.
5. This kit gripping on the frame.
6. **Mounting instruction for right side.**
7. Please leave all spacer´s/bushes in place.
8. Insert steel box ID.1 into the protector.
9. Insert bolt through the protector and gripping it on the frame.

Warning: We recommend use the glue of all threads. Medium strong.



