

MV5S

MV Agusta Brutale 910

ID.	Description	Cat.no.	Pcs
1	Bolt M12x80x1,25	908	2
2	Dural. cylinder	1137	2
3	Dural. cylinder 36mm	1191	2
4	Bolt M6x25	877	6
5	Bolt M4x12	876	4

INSTRUCTIONS:

- 1.) Prepare bolt ID1 and place all cylinders on it according to the picture below.(the middle part is already part of part ID.2)



- 2.) Mount this kit on the frame of motorcycle.
- 3.) Fit protector using three M6 bolts.
- 4.) Fit cover using two M4 bolts.

We recommend to use safety glue on all threads.

Ilustr. fotografi, místa montáže

