

KTM3-PKN

KTM125/200/300 Duke

Mounting instruction:

Mounting kit left side:

Note.	Description	Cat.No	Quant
1	Duralumin cylinder	1112	1
2	Bolt M10x58x1,25	901	1
3	Washer M10	804	1
4	Crash protector	10,5/ X45/2,5	1

Mounting kit right side:

Note.	Description	Cat.No	Quant
1	Duralumin cylinder	1112	1
2	Bolt M10x58x1,25	901	1
3	Washer M10	804	1
4	Crash protector	10,5/ X45/2,5	1

Right side:

- Put on washer, dural. cylinder and crash protector on the bolt M10.
- Mount tis kit on swingarm.

Left side:

- Put on washer, dural. cylinder and crash protector on the bolt M10.
- Mount tis kit on swingarm.



The threaded bolts, use glue on the threads (medium-strength blue).

