

D10

Ducati Hyperstrada 821 (13-)

Montážní sada pro levou stranu

| ID | Popis | Cat.no. | ks |
|----|---|---------|----|
| 1 | Steel nut M12 | X12/X2 | 1 |
| 2 | Duralumin cylinder – 90mm | 1200 | 1 |
| 3 | Stainless steel bar 12(1,25)x425x30x30 | - | 1 |

Montážní sada pro pravou stranu

| ID | Popis | Cat.no. | ks |
|----|---------------------------|---------|----|
| 1 | Steel nut M12 | X12/X2 | 1 |
| 2 | Duralumin cylinder – 85mm | 1199 | 1 |
| 3 | | | |

Instructions:

- 1.) Dismount the long original bolt.
- 2.) Insert the steel rod (ID3) through the frame.
- 3.) Install duralumin rollers (ID2) on both ends of the rod.
- 4.) Attach the protector and insert the M12 steel nuts (ID1) to tighten the set

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

