

D13S

Ducati Scrambler 2015-

Left side kit

ID	Description	Cat.no.	pcs
1	Nut M12	X12	1
2	Dural. cylinder - 68,5mm	1212	1
3	Dural. adapter - 48mm	314	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2
6	Steel rod 12(1,25)x405x30x30		1

Right side kit

ID	Description	Cat.no.	pcs
1	Nut M12	X12	1
2	Dural. cylinder - 78,5mm	1213	1
3	Dural. adapter - 48	314	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2

Instructions:

1. Unsrew original bolt M12 from the frame of motorcycle.
2. Put steel rod M12 through the frame.
3. Put dural cylinders (ID2) and adapters (ID3) on both ends of steel rod.
4. Tighten both ends using nut M12.
5. Mount slider on the adapter using three bolts M6.
6. Mount coloured cover into the slider using two bolts M4.

We recommend to use the glue on all threads (medium strong).

