

H27

Honda CBF1000 2010-

Kit for the left side

ID.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M10x80mm	852	1
3	Dural. cylinder d=21mm	256	1
4	Nut M10 (safety)	810	1

Kit for the right side

ID.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M10x80mm	852	1
3	Dural. cylinder d=21mm	256	1
4	Nut M10 (safety)	810	1

Installation:

1. Installation of the left and right protector make in gripping about the attached photo above. Give the steel box M10 (ID. 1) on both bolt.
2. Put the duralumin cylinder (ID. 3) under the protector on the left side and use the bolt (ID. 2) for tightening.
3. Put the duralumin cylinder (ID. 3) under the protector on the right side and use the bolt (ID. 2) for tightening.
4. At first finish the one side and then mount the second side.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).



