

K23SDM

Kawasaki ER-6N 2009-2011

LEFT SIDE KIT

ID	Description	Cat.no.	Pcs
1	Adapter SLDM	537/B	1
2	Bolt M10x130x1,25mm	905	1
3	Bolt M8x60mm	838	1
4	Bolt M10x60mm	850	1
5	Dural. cylinder 40mm	DV12	1
6	Dural. cylinder 63mm	118	1
7	Dural. cylinder 22mm	117	1
8	Dural. adapter	528	1
9	Washer M10 (flat)	804	1
10	Bolt M6x20	1024	2
11	Washer M6	1023	2

RIGHT SIDE KIT

ID	Description	Cat.no.	Pcs
1	Adapter SLDM	537/B	1
2	Bolt M10x120x1,25mm	895	1
3	Bolt M8x40mm	835	2
4	Bolt M10x70mm	851	1
5	Dural. cylinder 50mm	DV13	1
6	Dural. cylinder 4,5mm	116	1
7	Dural. adapter	527	1
8	Washer M10 (flat)	804	1
9	Bolt M6x20	1024	2
10	Washer M6	1023	2



LEFT SIDE INSTRUCTIONS

- 1) Dismantle side fairing and bolts from the frame.
- 2) Assembly fitting kit according to the picture above (page 1).
- 3) Fit this kit into the frame of motorcycle.
- 4) Fit SLD adapter ID1 and dural cylinder ID5 into the fitting kit using bolt ID4.
- 5) Fit slider using bolts ID10 and washers ID11.

We recommend to use safety glue on all threads (medium strong).



RIGHT SIDE INSTRUCTIONS

- 1) Dismantle side fairing and bolts from the frame.
- 2) Assembly fitting kit according to the picture above (page 1).
- 3) Fit this kit into the frame of motorcycle.
- 4) Fit SLD adapter ID1 and dural cylinder ID5 into the fitting kit using bolt ID4.
- 5) Fit slider using bolts ID9 and washers ID10.

We recommend to use safety glue on all threads (medium strong).

